

FIG.1






FIG.2





	120	142	144
PRODUCT CONFIGURATOR	SEARCH A		REQUEST NEW QUOTE  138 140  QUOTE SUBMIT ORDER
USER NAME: JOHN DOE 2/21/2001	CUSTOM QUOTE	ER NAME: NUMBER:	
CUSTOMER DETAILS SYSTEM  1////// 2 3	ENGINE 130 GENERATOR 4	DISTRIBUTION BREAKER 5	PRICING 134 122 -
CUSTOMER LOOKUP			REQUIRED FOR ORDER
148 CUSTOMER NAME CUSTOMER NUMBER		Q LOOK U	160 P
152 BILLING INFORM  ADDRESS LINE 1	ATION	<del> 150</del>	
152 ADDRESS LINE 2			
154 — CITY 156 — STATE 158 — ZIP			
	[	CONTINUE	—162 ]
			38
	PREVIEW Q	UOTE   SAVE QU	JOTE SUBMIT ORDER

	170	142	144
	SEARCH ALL	MY QUOTES	REQUEST NEW QUOTE
		361	38
PRODUCT CONFIGURATOR USER NAME: JOHN DOE	<u> </u>	<del></del>	QUOTE SUBMIT ORDER
2/21/2001	CUSTOMER QUOTE NU		3
	ENGINE 130 D		132 134 122
CUSTOMER DETAILS SYSTEM	GENERATOR B	REAKER	PRICING —
1 2 // 3	4 .   5	5	6
PROJECT DETAILS172			REQUIRED FOR ORDER
180	SHIPP	ING INFORM	ATION -174
PROJECT NAME  182 LOCATION		SS LINE 1	
184 CONTACT NAME	<del></del>	SS LINE 2	
186 CONTACT EMAIL		194 CITY	
188 — CONTACT PHONE		96 ✓ STATE [	
		<sub>08</sub> ZIP[	
190 CONTACT FAX			178
ENGINEERING FIRM ~ 176	216 EL	ECTRICAL C	ONTRACTOR
200		ANY NAME	
ENGINEER	218 20N	TRACTOR	
NAME	206	NAME L	
204 CITY STATE		NTRACTOR E-MAIL	
208 COUNTRY	CON	NTRACTOR [	
ENGINEER 210 E-MAIL	222	PHONE L	
ENGINEER	224	NTRACTOR FAX	]
212 PHONE			
CENGINEER 214 FAX			
			CONTINUE 226
	1	36	138140
	PREVIEW QU	JOTE SAVE C	QUOTE SUBMIT ORDER



	25	142	144			
	SEARCH	ALL MY QUOTES	REQUEST NEW QUOTE			
		<del>'</del>	38 /140			
PRODUCT CONFIGURATOR USER NAME: JOHN DOE	<u> </u>		QUOTE   SUBMIT ORDER			
2/21/2001		OMER NAME: TE NUMBER:				
CUSTOMER DETAILS SYSTEM GENERATOR BREAKER PRICING 134 122						
BEITHES STATE	4 ////	5	6			
ENGINE-GENERATOR			REQUIRED FOR ORDER			
252 —		_ 262				
MAKE OF GENERATOR SELECT ON	E 🗸	PT CONFIGURAT	ION SELECT ONE			
254 GOVERNOR/LOAD SELECT ON	IE 🗸	1 2	RIP SELECT ONE			
SHARING MODULE SELECT ON VOLTAGE REGULATION SELECT ON	IF \\	266 BREAKER T	RIP SELECT ONE			
256		UNIT MO				
258 ALARM SHUTDOWN SELECT ON		BREAKER S	IZE SELECT ONE 🗸			
GROUNDING SYSTEM SELECT ON 260	E \\	200				
270						
)	<del></del>					
MX BOOO LED ANNUNCIATOR YE	s 🗸		274			
SPARE INPUT NO.1 SELECT ON	IE 🛆	EVENT MESSAGE				
SPARE INPUT NO.2 SELECT ON	IE 🛆	EVENT MESSAGE				
SPARE INPUT NO.3 SELECT ON	IE 🗸	EVENT MESSAGE				
SPARE INPUT NO.4 SELECT ON	IE 🗸	EVENT MESSAGE				
	······					
		[	CONTINUE 276			
	/	136	138140			
	PREVÍ	EW QUOTE SAVE	QUOTE SUBMIT ORDER			

FIG.7

280						
SEARCH ALL MY QUOTES REQUEST NEW Q	UOTE					
136 138 14	0					
PRODUCT CONFIGURATOR USER NAME: JOHN DOE  PREVIEW QUOTE SAVE QUOTE SUBMIT ORI	DER					
2/21/2001 CUSTOMER NAME: QUOTE NUMBER:						
7124 PROJECT 126 7128 ENGINE 130 DISTRIBUTION 132 134 132						
CUSTOMER DETAILS SYSTEM GENERATOR BREAKER PRICING  1 2 3 4 5 7 7 6						
DISTRIBUTION BREAKER   REQUIRED FOR ORD	 )FR					
= 1240 MENTER	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
282 TRIP UNIT TYPE \\ \nabla \						
TRIP UNIT MODEL						
1 SELECT FRAME SIZE SELECT ATS SELECT LOAD BLOCK PRIORITY	70					
2 SELECT FRAME SIZE SELECT ATS SELECT LOAD BLOCK PRIORITY	刁					
3 SELECT FRAME SIZE SELECT ATS SELECT LOAD BLOCK PRIORITY	词					
4 SELECT FRAME SIZE SELECT ATS SELECT LOAD BLOCK PRIORITY	回					
5 SELECT FRAME SIZE V SELECT ATS V SELECT LOAD BLOCK PRIORITY						
6 SELECT FRAME SIZE V SELECT ATS V SELECT LOAD BLOCK PRIORITY						
7 SELECT FRAME SIZE V SELECT ATS V SELECT LOAD BLOCK PRIORITY						
8 SELECT FRAME SIZE V SELECT ATS V SELECT LOAD BLOCK PRIORITY	一一					
9 SELECT FRAME SIZE V SELECT ATS V SELECT LOAD BLOCK PRIORITY	<del></del>					
10 SELECT FRAME SIZE V SELECT ATS V SELECT LOAD BLOCK PRIORITY	一一					
11 SELECT FRAME SIZE SELECT ATS SELECT LOAD BLOCK PRIORITY	ا تب					
12 SELECT FRAME SIZE V SELECT ATS V SELECT LOAD BLOCK PRIORITY	ا ٽب					
286 J 290 J CONTINUE 292	<u> </u>					
136						
PREVIEW QUOTE SAVE QUOTE SUBMIT ORDER						